

Important installation advice

On the FAI Camshaft Kit CSK3478 and individual cams C347 and C348, there are no timing marks to aid in alignment. When installing these parts, the correct installation tool must be used to ensure correct timing alignment.

The tool is available from automotive tool suppliers and distributors, and full fitting instructions are available on Autodata or similar workshop manual providers.

